



### Ozone Safe Ultrasonic Cleaner Biodegradable and Solvent Free



#### Description

Chem-Crest 715 mild liquid detergent is useful in many applications requiring good detergency and wetting, especially on hard surfaces. It is a biodegradable, non-etching and neutral pH detergent.

#### Substrate Compatibility

Chem-Crest 715 is safe on copper, beryllium copper alloys, brass, gold, silver, stainless steel, aluminum, plastics, glass, nickel alloys and ceramics when used as directed.

#### Typical Contaminants Removed

Chem-Crest 715 removes oils, lubricants, particles, fingerprints, light silicone oils, mold release compounds, buffing compounds and airborne contaminants.

#### Operating Concentration

Chem-Crest 715 is used at 3-10% by volume in ultrasonic cleaning applications for light to heavy contaminants. Normal operating temperatures: 130°-160°F.  
Recommended rinsing temperature: 110°-150°F.

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.



**CREST ULTRASONICS • PO Box 7266 • Scotch Road • Trenton, NJ 08628  
609-883-4000 • Fax-609-883-6452 • WWW.CREST-ULTRASONICS.COM**

#### Storage

Avoid freezing conditions.

#### Disposal Methods

Dispose of in accordance with Federal, State and Local Government regulations.

#### Safety Precautions

See Material Safety Data Sheet.

#### Availability

Chem-Crest 715 is available in cases of 4x1 gallons and in 55 gallon containers.

#### Physical Data

Flash Point: None  
Specific Gravity: 1.02  
pH: 5% solution = 8.1+/-0.5  
Solubility in Water: Complete  
Volatiles: N/A

*\*These values do not constitute specifications*

#### India Office

**Crest Ultrasonics India Pvt Ltd • C-11, Functional Industrial Estate • Patparganj • Delhi 110092 • INDIA  
Phone (91) 11 22164532 • (91) 98100 33631 • info@crestultrasonicsindia.com • www.crestultrasonicsindia.com**